


LEDGE®


4 In A Row Assembly Guide




▲ BEFORE YOU BEGIN

Unpack and lay all pieces flat on a padded surface to avoid scratching or damaging them. Locate and count all parts before discarding any packaging.

PARTS



BOARD



**RIGHT LEG AND
LEFT LEG**




**SLIDE WITH SCREW
AND SLIDE STOP**



42 PLAYING PIECES (SEGES)
• 21 GREEN PIECES
• 21 BLUE PIECES


STEP 1

Position the unit with the front facing you. Align the left leg (L) with the matching L slots, then tap into place. If needed use a rubber mallet.





STEP 2

Align the right leg (R) with the matching slots and tap into place. If needed use a rubber mallet.




STEP 3

Once both legs are installed, remove the screw from the slide stop on the slide bar (A). Position the slide with the screw flange facing downward, then insert the left side first as indicated by the blue arrow (B).




STEP 4

Once the slide is inserted, move the stopper fully to the right and fit it into the L-shaped slot.



STEP 5


Once fully seated, slide the stopper to the left and secure the slide stop with the provided 5/8" screw.



STEP 6

Assembly Complete

We hope your new piece serves as the backdrop for life's most meaningful moments. We would love to see how you've styled your space, tag us @ledgelounger for a chance to be featured in our gallery!



For a PDF version of these instructions, please scan the QR code.



Para instrucciones en español, por favor escanea este código QR.



Pour des instructions en français, veuillez scanner ce code QR.

LEDGE[®]
THE ART OF OUTDOOR LIVING